


STANDARD CRANE AND DERRICK SIGNALS




EMERGENCY STOP




STOP



DOG EVERYTHING



MOVE SLOWLY



RAISE BOOM



LOWER BOOM



USE MAIN HOIST



USE WHIP LINE



LOWER



11139 Cutter Road • Meadville, PA 16335
Phone: 814-333-9600 • Fax: 814-336-3333

www.crawfordcustom.com


- Crane Inspections - Conventional, Hydraulic, Boom Truck, EOT (Electric Overhead Traveling), Man Lift, Scissor Lift, Jib Crane
- Crane Operator Training
- Crane Operator Licensing & Certification
- Overhead Crane Training
- Accident Investigation & Reporting
- Professional Witness Services



HOIST



**RAISE THE BOOM AND
LOWER THE LOAD**



**LOWER THE BOOM
AND RAISE THE LOAD**




**EXTEND BOOM
(Telescoping Booms)**



**RETRACT BOOM
(Telescoping Booms)**



SWING



TRAVEL



**TRAVEL
(One Track)**



**TRAVEL
(Both Tracks)**



**RETRACT BOOM
(Telescoping Booms)**



**EXTEND BOOM
(Telescoping Booms)**